

***skanti***

**INSTRUCTION MANUAL**

**SSB RECEIVER**

**Type R5001S**











**AND POWER PACK P5013S**

I N S T R U C T I O N M A N U A L

CONTENTS

1. INTRODUCTION	1-1
2. OPERATING INSTRUCTIONS	2-1
2.1. Tuning to 500 kHz and 2182 kHz	2-1
2.2. Tuning to an AI, FI or SSB Station in the Preselector Range	2-1
2.3. Tuning to an FI or SSB Station in the Duplex Ranges	2-1
2.4. Tuning to an AM Station	2-2
2.5. Operating Controls and Their Functions	2-2
3. INSTALLATION	3-1
3.1. Disassembling the Receiver	3-1
3.2. Connection to the Permanent Installation	3-1
3.3. Earth Connection	3-1
3.4. Antenna	3-1
3.5. Exchanging the Input Impedance	3-1
3.6. Remote Speaker	3-2
3.7. Muting	3-2
3.8. External Master Oscillator	3-2
4. TECHNICAL DATA	4-1
5. TECHNICAL DESCRIPTION	5-1
5.1. Mechanical	5-1
5.2. Circuit Description, General	5-1
5.3. Circuit Summary, Signal Path	5-1
5.4. Circuit Description, Signal Path Boards	5-2
5.5. Circuit Summary, Frequency Synthesizer	5-4
5.6. Circuit Description, Frequency Synthesizer	5-5
5.7. Circuit Summary, Frequency Selection	5-8
5.8. Circuit Description, Frequency Selection	5-8
5.9. Circuit Summary, P 5013, 24V DC/AC Power Pack	5-10
5.10. Circuit Description, P 5013, 24V DC/AC Power Pack	5-10
6. SIMPLE SERVICE	
6.1. Incorrect Operation	6-1
6.2. Battery	6-1
6.3. Replacement of Fuses	6-1

7. REPAIR AND ALIGNMENT

7.1.	Introduction	7-1
7.2.	Cross Slot Screws	7-1
7.3.	Locating Subunits and Components	7-1
7.4.	Locating Faults	7-1
7.5.	Test Points	7-1
7.6.	AC Voltages	7-2
7.7.	DC Voltages	7-2
7.8.	Typical Sensitivity Levels	7-2
7.9.	Adjustments	7-2
7.10.	Realignment of Input Filters 	7-3
7.11.	 Realignment of 2nd Mixer and Clarifier Oscillator	7-6
7.12.	 Realignment of IF Amplifier Detector and AGC	7-6
7.13.	 ,  Realignment of AF Amplifier	7-7
7.14.	 ,  Frequency Adjustment of the TCXO	7-7
7.15.	 Realignment of VCO <sub>1</sub> and VCO <sub>2</sub>	7-7
7.16.	 Realignment of Loop Translator	7-8
7.17.	 Realignment of VCO <sub>3</sub>	7-9



















8. PARTS LISTS AND CIRCUIT DIAGRAMS

8.1.	Numbering	8-1
8.2.	Switches	8-1
8.3.	Terminals	8-1
8.4.	Voltages	8-1
8.5.	Test Points	8-1
8.6.	Symbol Explanation	8-1
8.7.	Abbreviations	8-4
8.8.	Parts List	8-5
8.9.	Diagrams	8-46

## LIST OF ILLUSTRATIONS

	Page
Front panel and Operatings Controls	1 - 2
Location of Circuit Boards	8 - 45

### LIST OF DIAGRAMS

Block Diagram, Signal Path	8 - 46
Block Diagram, Frequency Synthesizer	8 - 47
Block Diagram, Frequency Selection	8 - 48
Block Diagram, P 5013 24V DC/AC Power Pack	8 - 49
 Wiring Diagram R 5001 S-1, S-2	8 - 51
 Filterboard	8 - 53
 Input Filters	8 - 55
 38 MHz Filter	8 - 57
 2. Mixer	8 - 59
 IF Filters	8 - 61
 IF Amplifier Detector and AGC	8 - 63
 ,  AF Amplifier	8 - 65
 Frequency Dividers	8 - 67
 Loop Translator	8 - 69
 VCO <sub>1</sub> and VCO <sub>2</sub>	8 - 71
 VCO <sub>3</sub>	8 - 73
 Display and Keyboard	8 - 75
 Synthesizer Control	8 - 77
 Loop 3 Divider	8 - 79
 Noise Generator	8 - 81
 3 MHz Lock	8 - 83
Power Pack Wiring Diagram P 5013	8 - 85